


Getting Started Step-by-Step


- 1** After program has started select language you would like to work in.




- 2** Click on Template Icon to select the template which matches the label your kit came with.




- 3** Click on Background Icon to select one of the included backgrounds.



- 4** Depending on the Background selected, your label should now look like this.




- 5** Click on the Text Icon to add your desired text. Add color to text, change fonts, size, style and alignments as you please.



- 6** Now you can Print!!!

Applying the Label and Using the Applicator

Once the CD Stomper applicator is removed from the packaging, place it on a flat surface and twist the small knob sticking out of the top to unlock it and allow the spring action mechanism to work. 1. To apply a label, you must first remove the label from the label stock after it has been printed. 2. Place the label, with the graphics side down, adhesive side up, over the plunger portion of the CD Stomper. 3. Take the CD you wish to label and place it on the small knob that is on top of the plunger. Remember to place it data side up. 4. Using 3 fingers, grab the knob so that the tips of your fingers come in contact with the CD. Now, push down on the spring loaded plunger so the CD comes into contact with the label. You may now lift back up on the plunger and your CD has just been "Stomped". 5. It is a good idea to rub the label down onto the CD to remove unwanted air bubbles and to permanently affix the label to the CD. The bottom rubber side of the cdstomper is a good place to place the cd to perform this final step.



1996 CD Stomper, Patent Pending, ©1999 STOMP, INC.

USER GUIDE

CD STOMPER

Quick Start For Macintosh

PRO

- * Maintain 20mb of hard disc space available while running this program.
- * You must have at least 16mb of RAM.

Follow these instructions for quick start on Macintosh

Installing:

Insert CD Stomper Pro CD-ROM into CD-ROM Drive and wait for the CD Stomper Pro CD Icon to appear on your desktop. Double click on the CD Stomper Icon to open up the CD. Find and double click on the icon Stomp 3.0 (Select the icon for the appropriate platform and language).

Starting:

From the desktop, double click on your hard disc Icon. Find and select folder named Stomper3.0. Within this folder you will find the Application Program named Stomper3, double click on this file to run the Stomper Pro Software.

! IMPORTANT PLEASE READ !

While running the software, you will need to keep the CD in the CD-ROM drive. The Stomper software program runs off the hard drive and uses the CD-ROM drive to pull over 500mb's of background picture images. If you do not need access to the images (if you are importing your own artwork) the CD does not need to be in the CD-ROM drive to run the program except on start up and when accessing Backgrounds or Clip Art.

Upgrades: Please keep in touch with us on the Internet at www.labelcd.com for free upgrades to the current version of the software you have.

Selecting and Moving Objects: Stomper software has drag and drop functionality. To move a selected object, click on that object, hold the mouse button down and drag that object to your desired location. For more precise movements of selected objects you may also use the arrow keys on your keyboard.

Shifting the Images to compensate for misaligned printer registration: This function is needed only if the backgrounds do not line up properly over the die cut labels on the label stock. Shifting the entire page is done by using the 2,4,8 and 6 buttons that are on the 10 key pad on your Keyboard as arrows to shift the entire page in each direction. When using this function, make sure that the numlock is set to numbers.

Using other programs: If you want to design your own artwork in a 3rd party piece of software like Photoshop or CorelDRAW, we have provided templates of the label stock for Macintosh. The templates are provided as BMPs, Picts and EPSs and can be found on the Stomper CD under templates. Specific templates in individual applications can be downloaded off of our Internet site at www.labelcd.com.

Helpful Hints:

Try printing on a plain piece of paper to check print quality and alignment.

When doing test prints, set printer to lowest resolution for a quick print.

Always set printer to maximum printable area.

Allow ink to dry after printing.

When handling discs, do not touch the surface of the disc.

Do not expose the disc to dust, smoke, sunlight, heat, cold or humidity.

Never remove label once it has been applied.

Contact Us Stomp Inc., 2950 Airway Ave #B1, Costa Mesa, CA 92626. You may also call us (M-F 8 to 5 pst) at 714-250-6771 or fax us at 714-250-6775 or contact us through our Internet site at www.labelcd.com